


CHARCOAL FILTER INSTALLATION INSTRUCTIONS

1. Remove plastic cover from charcoal filter and place in Air Cleaner Cabinet as shown on downstream side of air flow direction.
2. Install metal clips as shown, both top and bottom, over the flanges on cell guide. Make sure that charcoal filter overlaps the front and back flanges on cabinet after clips are installed.





Filter Clip